

4. MAINTENANCE SCHEDULE

	INITIAL SERVICE PERIOD	REGULAR SERVICE PERIOD				
		500 miles	1 month 500 miles	3 months 1,500 miles	6 months 3,000 miles	12 months 6,000 miles
This maintenance schedule is based upon average riding conditions. Machines subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.						
ENGINE OIL—Change.	●		○			
CENTRIFUGAL OIL SCREEN—Clean.						○
OIL FILTER SCREEN—Clean.						○
SPARK PLUG—Clean and adjust gap or replace if necessary.					○	
CONTACT POINTS AND IGNITION TIMING—Clean, check, and adjust or replace if necessary.	●				○	
*VALVE TAPPET CLEARANCE—Check, and adjust if necessary.	●				○	
*CAM CHAIN TENSION—Adjust.	●				○	
POLYURETHANE FOAM AIR FILTER ELEMENT—Clean and oil.			(Service more frequently if operated in dusty areas)			
*CARBURETOR—Check, and adjust if necessary.	●				○	
THROTTLE OPERATION—Inspect cable. Check, and adjust free play.	●				○	
FUEL FILTER SCREEN—Clean.					○	
FUEL LINES—Check.					○	
*CLUTCH—Check operation, and adjust if necessary.	●				○	
DRIVE CHAIN—Check lubricate, adjust if necessary.	**●	○				
SPARK ARRESTOR—Purge			○			
BRAKE SHOES—Inspect, and replace if worn.					○	
BRAKE CONTROL LINKAGE—Check linkage and adjust free play if necessary.	●				○	
*WHEEL RIMS AND SPOKES—Check. Tighten spokes and true wheels, if necessary.	●				○	
TIRES—Inspect and check air pressure.	●	○				
FRONT FORK OIL—Drain and refill.	***●					○
FRONT AND REAR SUSPENSION—Check operation.					○	
REAR FORK BUSHING—Grease, check for excessive looseness.					○	
*STEERING HEAD BEARINGS—Adjust.						○
BATTERY—Check electrolyte level, and add water if necessary.	●		○			
LIGHTING EQUIPMENT—Check and adjust if necessary.	●	○				
ALL NUTS, BOLTS, AND OTHER FASTNERS—Check security and tighten if necessary.	●	○				

Items marked * should be serviced by an authorized Honda dealer, unless the owner has proper tools and is mechanically proficient. Other maintenance items are simple to perform and may be serviced by the owner.

** INITIAL SERVICE PERIOD 200 MILES.

*** INITIAL SERVICE PERIOD 1,500 MILES.