



POOR HANDLING

- | | POSSIBLE CAUSE |
|--|---|
| 1. If steering is heavy | (1) Steering stem adjustment too tight
(2) Damaged steering head bearings |
| 2. If either wheel is wobbling | (1) Excessive wheel bearing play
(2) Bent rim
(3) Improperly installed wheel hub
(4) Swing arm pivot bearing excessively worn
(5) Bent frame
(6) Swing arm pivot adjusting bolt (right side) too tight
(7) Wheel out of balance |
| 3. If the motorcycle pulls to one side | (1) Improperly adjusted shock absorber
(2) Front and rear wheels not aligned
(3) Bent front fork
(4) Bent swing arm
(5) Improperly installed front fork brace |