

# MAINTENANCE SCHEDULE

Perform the PRE-RIDE INSPECTION in the Owner's Manual at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE, OR REPLACE IF NECESSARY.

C: CLEAN, R: REPLACE, A: ADJUST

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓ EVERY	ODOMETER READING (NOTE 3)						Refer to page	
			600 mi (1,000 km)	4,000 mi (6,400 km)	8,000 mi (12,800 km)	12,000 mi (19,200 km)	16,000 mi (25,600 km)	20,000 mi (32,000 km)		24,000 mi (38,400 km)
EMISSION RELATED ITEMS	* FUEL LINES				I		I		I	3-4
	* FUEL FILTER								R	3-4
	* THROTTLE OPERATION		I		I		I		I	3-5
	* CARBURETOR-CHOKE				I		I		I	3-6
	AIR CLEANER	NOTE 1		C	C	C	C	C	C	3-7
	CRANKCASE BREATHER	NOTE 2		C	C	C	C	C	C	3-7
	SPARK PLUGS			R	R	R	R	R	R	3-8
	ENGINE OIL	YEAR	R		R		R		R	2-3
	ENGINE OIL FILTER	YEAR	R		R		R		R	2-3
	* CARBURETOR-SYNCHRONIZATION		I		I		I		I	3-9
	* CARBURETOR-IDLE SPEED		I	I	I	I	I	I	I	3-10
	RADIATOR COOLANT				I		I		*R	3-10
	* RADIATOR CORE				I		I		I	3-11
	* COOLING SYSTEM HOSES & CONNECTIONS		I		I		I		I	3-11
	* EVAPORATIVE EMISSION CONTROL SYSTEM	NOTE 3				I		I		I
NON-EMISSION RELATED ITEMS	FINAL DRIVE OIL					I		I	R	2-11
	BATTERY	MONTH	I	I	I	I	I	I	I	3-13
	BRAKE FLUID (FRONT)	MONTH I 2 YEARS* R	I	I	I	*R	I	I	*R	3-13
	BRAKE SHOE/PAD WEAR			I	I	I	I	I	I	3-14
	BRAKE SYSTEM		I		I		I		I	3-14
	* BRAKE LIGHT SWITCH		I		I		I		I	3-16
	* HEADLIGHT AIM		I		I		I		I	3-16
	CLUTCH FLUID	MONTH I 2 YEARS* R	I	I	I	*R	I	I	*R	3-16
	CLUTCH SYSTEM		I		I		I		I	3-16
	SIDE STAND				I		I		I	3-17
	* SUSPENSION		I		I		I		I	3-17
	* NUTS, BOLTS, FASTENERS		I		I		I		I	3-19
	** WHEELS		I		I		I		I	3-18
** STEERING HEAD BEARINGS		I		I		I		I	3-19	

\* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED.

\*\* IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.

NOTE: 1. SERVICE MORE FREQUENTLY WHEN RIDING IN DUSTY AREAS.

2. SERVICE MORE FREQUENTLY WHEN RIDING IN RAIN OR AT FULL THROTTLE (U.S.A. ONLY).

3. '84 CALIFORNIA MODEL.

4. FOR HIGHER ODOMETER READING, REPEAT AT THE FREQUENCY INTERVAL ESTABLISHED HERE.